




Eld User Manual




bluehorseeld.com






Driver Login

- Open the bluehorse application.
- Enter the Username and Password.
- Press the Login button.




bluehorseeld.com






Connect to Vehicle

- Locate the diagnostic port.
- Attach the wire to the diagnostic port.
- Attach other side of the wire to the device.
- Press Connect signal red button on top right.
- Press scan button if no device found.
- Select the available device.
- ELD will connect with App and signal button should turn green




bluehorseeld.com






Vehicle & Trailer

- Press Vehicle icon next to your name.
- Press vehicle Name and select Vehicle.
- Press Trailer Name and select Trailer.
- Press the Save button




bluehorseeld.com






Change duty status

- Press the status button.
- Select your current duty status.
- Odometer will be auto picked.
- Location will be auto picked.
- Press the save button.




bluehorseeld.com






Personal use

- Press the status button.
- Select the personal use checkbox below duty status.
- Enter the note.
- Press the save button.




bluehorseeld.com






Yard move

- Press the status button.
- Select the yard move checkbox below duty status.
- Enter the note.
- Press the save button.



bluehorseeld.com






DVIR

- Press the DVIR button at the bottom.
- Select the form and press on inspect.
- Select all checkboxes and then finish.
- Select vehicle condition.
- Add signature and finish DVIR.
- Click on save button to complete DVIR




bluehorseeld.com






View and certify

- Press the logs button at the bottom.
- Current day logs will show there.
- Select the date to view previous logs.
- Press Show all to view all logs.
- Press certify button on top right corner.
- Verify your info & press click agree to certify.



bluehorseeld.com






Co-driver

- Open the left side menu
- Press Co-driver Login.
- Enter username and password.
- Press the Login button.
- Open the left side menu.
- Press switch co-driver.
- Press view or make driver.
- Enter the password and login.




bluehorseeld.com






Roadside Inspection

- Open the left side menu.
- Press FMCSA.
- Press Start Review.
- Handover the device to the Inspector.




bluehorseeld.com






Data Transfer

- Open the left side menu.
- Press roadside inspection.
- Press Email or Data Transfer.
- Enter the comment and press transfer.



bluehorseeld.com






Edit request

- Open the left side menu.
- Press the Requests.
- Accept or Reject the request.
- Enter the note and press save.



bluehorseeld.com






Malfunctions Event

- 'M' icon will blink on the top.
- Press 'M' icon on the top.
- List of events will show up.
- Press the event to check the details.



bluehorseeld.com





Data Diagnostic Event

- 'D' icon will blink on the top.
- Press 'D' icon on the top.
- List of events will show up.
- Press the event to check the details.



bluehorseeld.com

